Vibes MD850 General Update Installation Instructions



1 Download latest Vibes Release

- Navigate to https://my.mayer-emi.at/products/vibes-md850
- Navigate to Software Updates
- (1) Download latest version for manual instal





2 Copy to MEMI USB Stick

Copy the File "MD850-Update-V X X .md850.pkg" into the root directory of the MEMI USB Stick

(1) Ensure the USB Pen Drive has the name "MEMI"

- or -

(2) Ensure there exist a file named "MEMI.config" in the root of the USB Pen Drive (The file can be empty)



MAYER

3 Insert USB Stick

1. Insert the USB Pen Drive in one of the USB Host Ports on the back of the Vibes



4 Installer screen

Wait for the installer screen to show up. Doublecheck the version to install.

- 1. Press first wheel knob to start installation
- 2. Press fourth wheel knop to exit the installer without installation

Vibes Updat Vibe Vibes System Upda Press Wheel 1 to Press Wheel 4 to	E VXX A s Update VXX te to VXX run Installation Exit	ers		SEQ/APR FX ARR. MASTER	CLIPS MATRIX DRUM VOICE
Install			Exit	MID	DIAG
			2	ESC L	

MAYER

4.1 Installation done

After installation has started, the installation steps are logged.

The synthesizer engine will start up automatically after installation has finished.



MAYER

5 Check version

- 1. Select the SETUP / DIAG pane on the touch screen
- 2. Check for Version "X.X Rev:X"

PERFOR	MIXER WIFI	PART A	CFG A VOI	CE A FX A ARP A		IPMIDISETU	P	SEQ/APR FX	
MIDI Input:				Event Filter: MIDI CC MIDI NOTE	Physical Used Virtual	: 3929420 kb : 391576 kb : 3929420 kb		ARR. MASTER	DRUM VOICE
22	21 52	FX	49.0 C	INFO: VIBES X-VA Synthes: Revision: cR314 Sevial: IP(Eth/Vifi): Update: Touch But	Check f	For Updates			
	\bigcirc		\bigcirc	0)			MIDI ESC L	DIAG ENTER

MAYER